

# INSTRUCTION MANUAL GALILEO COMFORT

## INSTALLATIONSANLEITUNG GALILEO COMFORT - ADAPTIVE WHITE

### CAUTION:

1. The power must be turned off before installation.
2. The installation requires expert knowledge and must be performed by an electrician or a similar qualified person.
3. Before installing the product, please check if the local voltage frequency corresponds with the product requirements.
4. Do not install the luminaire if it is under mechanical force of any kind.
5. Only install the luminaire with appropriate fixing materials.
6. The panel requires an input current of 700 mA per channel. Only connect converters which are configured and released by LEDON.
7. The panel is designed for indoor use only.
8. When cleaning the fixture, turn power off and let it cool down completely. Clean the fixture with a soft cloth and a PH neutral detergent.
9. The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
10. The light source contained in this luminaire shall only be replaced by the manufacturer.

### SICHERHEITSHINWEISE:

1. Schalten Sie die Spannungsversorgung vor der Installation aus.
2. Die Installation setzt Fachkenntnisse voraus und muss von einer qualifizierten Fachkraft, wie einem Elektriker oder einer ähnlich qualifizierten Person, durchgeführt werden.
3. Prüfen Sie vor der Installation, ob die lokale Spannungsversorgung mit den Produkthanforderungen übereinstimmt.
4. Installieren Sie die Leuchte nicht, wenn auf diese mechanische Kraft jeglicher Art wirkt.
5. Installieren Sie die Leuchte nur mit passendem Befestigungsmaterial.
6. Das Panel benötigt eine Stromstärke von 700 mA pro Kanal. Verwenden Sie ausschließlich einen von LEDON freigegebenen Konverter.
7. Das Panel ist nur für den Einsatz in Innenräumen geeignet.
8. Wenn Sie die Leuchte reinigen, schalten Sie die Spannungsversorgung aus und warten Sie bis die Leuchte komplett abgekühlt ist. Reinigen Sie die Leuchte mit einem weichen Tuch und pH-neutralem Reinigungsmittel.
9. Das äußere flexible Kabel dieser Leuchte kann nicht ersetzt werden; wenn das Kabel beschädigt ist, muss die Leuchte entsorgt werden.
10. Die in dieser Leuchte enthaltene Lichtquelle darf nur durch den Hersteller ersetzt werden.



